§ 39.65

of licensed materials and actions to obtain suitable radiation survey instruments as required by §39.33(b).

 $[52~{\rm FR}~8234,~{\rm Mar}.~17,~1987,~{\rm as}~{\rm amended}~{\rm at}~67~{\rm FR}~77652,~{\rm Dec.}~19,~2002]$

§39.65 Personnel monitoring.

- (a) The licensee may not permit an individual to act as a logging supervisor or logging assistant unless that person wears, at all times during the handling of licensed radioactive materials, a personnel dosimeter that is processed and evaluated by an accredited National Voluntary Laboratory Accreditation Program (NVLAP) processor. Each personnel dosimeter must be assigned to and worn by only one individual. Film badges must be replaced at least monthly and other personnel dosimeters replaced at least quarterly. After replacement, each personnel dosimeter must be promptly processed.
- (b) The licensee shall provide bioassay services to individuals using licensed materials in subsurface tracer studies if required by the license.
- (c) The licensee shall retain records of personnel dosimeters required by paragraph (a) of this section and bioassay results for inspection until the Commission authorizes disposition of the records.

 $[52~{\rm FR}~8234,~{\rm Mar}.~17,~1987,~{\rm as}~{\rm amended}~{\rm at}~65~{\rm FR}~63752,~{\rm Oct.}~24,~2000]$

§39.67 Radiation surveys.

- (a) The licensee shall make radiation surveys, including but not limited to the surveys required under paragraphs (b) through (e) of this section, of each area where licensed materials are used and stored.
- (b) Before transporting licensed materials, the licensee shall make a radiation survey of the position occupied by each individual in the vehicle and of the exterior of each vehicle used to transport the licensed materials.
- (c) If the sealed source assembly is removed from the logging tool before departure from the temporary jobsite, the licensee shall confirm that the logging tool is free of contamination by energizing the logging tool detector or by using a survey meter.
- (d) If the licensee has reason to believe that, as a result of any operation

involving a sealed source, the encapsulation of the sealed source could be damaged by the operation, the licensee shall conduct a radiation survey, including a contamination survey, during and after the operation.

- (e) The licensee shall make a radiation survey at the temporary jobsite before and after each subsurface tracer study to confirm the absence of contamination.
- (f) The results of surveys required under paragraphs (a) through (e) of this section must be recorded and must include the date of the survey, the name of the individual making the survey, the identification of the survey, instrument used, and the location of the survey. The licensee shall retain records of surveys for inspection by the Commission for 3 years after they are made.

§ 39.69 Radioactive contamination control.

- (a) If the licensee detects evidence that a sealed source has ruptured or licensed materials have caused contamination, the licensee shall initiate immediately the emergency procedures required by § 39.63.
- (b) If contamination results from the use of licensed material in well logging, the licensee shall decontaminate all work areas, equipment, and unrestricted areas.
- (c) During efforts to recover a sealed source lodged in the well, the licensee shall continuously monitor, with an appropriate radiation detection instrument or a logging tool with a radiation detector, the circulating fluids from the well, if any, to check for contamination resulting from damage to the sealed source.

Subpart E—Security, Records, Notifications

§ 39.71 Security.

(a) A logging supervisor must be physically present at a temporary jobsite whenever licensed materials are being handled or are not stored and locked in a vehicle or storage place. The logging supervisor may leave the jobsite in order to obtain assistance if a source becomes lodged in a well.